



WOODEN TABLE CARE AND MAINTENANCE - IMPORTANT INFORMATION

- Do not place any hot objects directly onto the surface without proper protection: always use mats and coasters with cork/felt backing underneath. Avoid mats and coasters with plastic/rubber as they can leave un-reversible marks on the surface.
- Never use sharp items on the surface of the product; knives and utensils may damage the surface. It is advisable to place a mat under paper when writing.
- Do not place your furniture next to a heat source such as a fire or radiator.
- Do not sit nor climb on your furniture.
- Do not use detergents, abrasive liquids or intensive cleaner as this will severely damage the surface.
- Clean up any liquid spilled onto the table using an absorbent microfiber cloth. PH neutral soap solution and water can be used to clean the surface. Please ensure the surface is left clean and dry. This should avoid any permanent stain.
- Never spray directly onto the table. Spray the microfiber cloth instead. This prevents chemical pooling, which can soften the finish.
- Never leave spilled liquids over a longer period of time. For example a wet vase base can still result in a stain when left too long.